



How to Change the Waste Toner Bottle on Your Canon Series Machine

1. Open the panel door (located next to tray 1)



2. Remove the waste toner bottle



For More Information:

Contact an Advance Expert:

410.628.0490 or Dispatch@advancestuff.com



3. Open the new waste toner bottle and insert into the machine



4. Close the panel door

[Click here to view our how-to video!](#)

For More Information:

Contact an Advance Expert:

410.628.0490 or Dispatch@advancestuff.com